

ELBA
TALENT FOR COOKING



BUILT-IN 60 CM GAS OVENS

ELBA

Fisher & Paykel Italy Appliances SpA
Via Fabbian Matteo, 7
31030 Borso del Grappa (TV)
Italy

Tel: +39 0423 9121
Fax: +39 0423 912440

Email: info@elba-cookers.it
www.elba-cookers.it

582343 - 07/2013

 Made in Italy 

GAS COOKING AWARENESS

The **touch control electronic timer** is designed in perfect harmony with the oven's aesthetic. Thanks to a control panel made entirely of glass, the cleaning is extremely simple; with a simple touch you can set the cooking time.

Combining **all-glass aesthetic** with high gas cooking performance, the new gas ovens are the perfect marriage of contemporary design and heating efficiency.

Smooth control panel design provided with the **electronic** digital clock with minute minder to give modern look to your ELBA gas oven.

Closed door grilling ensures that heat is distributed omogeneously and food is properly cooked with more even crispy effect.

For those of us who are conscious of the environment, it also ensures that heat is used more efficiently. It is also an additional safety measure for children.

Some Elba gas ovens are provided with **catalytic panels**. Fat residues are continuously broken down and your oven is clean even in those hard-to-reach spots.

The **oven cavity has increased in size providing more usable volume**. A new and innovative oven seamless cavity design is provided with the most efficient insulation system to make it possible the best cooking performance with lower gas consumption.

The full glass inner door **with removable glass** is available upon request for easier and perfect cleaning.



The **forced air convection** mode cuts down on overall cooking time, allowing roasted foods to retain more moisture. Suitable for delicate dishes that require heat concentration at the base, whilst gently cooking the top.

Innovative cooling tangential fan system to keep the oven's external surfaces at low and safe temperatures.

The **frameless** cavity style just perfectly matches our ELBA range of electric ovens too.

The **seamless oven cavity** is provided with an easy-to-clean dark grey enamel, to ensure a thoroughly clean oven with the minimum of fuss.

New and redesigned oven door hinges allows for a smooth and silent close.

OVEN FUNCTIONS



Oven light

The oven light is ideally positioned on the upper side of the cavity to ensure excellent overview of the interior



Lower gas burner

Ideal for use at the end of a cooking cycle to brown the base of your food.



Grill

Fast, extremely powerful grill ensures best grilling and browning results and perfect browning



Rotisserie

A powerful and silent rotisserie motor ensures that the heaviest pieces of meat are constantly turned over the entire grilling cycle



Forced air convection with lower gas burner

This function ensures you optimal results for cooking dishes that need a higher cooking in the lower side.



Defrost

Fan only without heating for defrosting frozen food

KEY FEATURES



Touch control electronic timer

It is perfectly smooth which makes it extremely easy to clean



Electronic digital timer

The easy to use electronic digital timer supports you through the cooking process so that your food is perfectly cooked when you are out.



Close door grilling

To help food retain natural juices and moisture, enhancing the overall dish's flavour



Cooling system

A highly efficient cooling system designed to keep the temperatures of oven's surfaces down during the cooking process



Removable inner glass

Easily removable inner glass without visible screw holes, rubber seals or notches which means that it can be quickly and easily cleaned.



Catalytic self-cleaning panels

Owing to the catalytic panels, food and juices splashing from the baking tray are decomposed already during the cooking process



512-731 X

Built-in 60 cm fan gas oven with grill and rotisserie

Key features

Stainless steel design
Electronic digital clock with minute minder
Rotisserie
Flame failure safety device
Electronic ignition
Easy removable door
Removable inner glass door
Cooling fan
Catalytic self-cleaning panel
Forced air convection mode

Oven accessories:

tray, shelf, shaped shelf, rotisserie kit, fan filter

Overall dimensions:

H 595 x W 595 mm

Also available without fan:

MODEL 511-731 X



KEY FEATURES



OVEN FUNCTIONS



512-7GTC

Built-in 60 cm **fan gas oven** with grill and rotisserie

Key features

All-glass design
Touch control electronic timer
Rotisserie
Flame failure safety device
Electronic ignition
Easy removable door
Removable inner glass door
Cooling fan
Catalytic self-cleaning panel
Forced air convection mode

Oven accessories:

tray, shelf, shaped shelf, rotisserie kit, fan filter

Overall dimensions:

H 595 x W 595 mm

Colours also available:

MIRROR MODEL: 512-7GTC M



510-821 X

Built-in 60 cm gas oven with **thermostatic electric grill** and rotisserie

Key features

Stainless steel design
Rotisserie
Flame failure safety device
Electronic ignition
Cooling fan
Easy removable door
Minute minder

Oven accessories:

tray, shelf, rotisserie kit

Overall dimensions:

H 595 x W 595 mm

Colours also available:

BLACK MODEL: 510-821 BK

WHITE MODEL: 510-821 WH

BROWN MODEL: 510-821 BN



KEY FEATURES



OVEN FUNCTIONS



KEY FEATURES



OVEN FUNCTIONS





510-721 X

Built-in 60 cm gas oven with grill and rotisserie

Key features

Stainless steel design
Rotisserie - Minute minder
Flame failure safety device
Electronic ignition
Cooling fan
Easy removable door

Oven accessories:

tray, shelf,
rotisserie kit

Overall dimensions:

H 595 x W 595 mm

Colours also available:

BLACK MODEL: 510-721 BK

WHITE MODEL: 510-721 WH

BROWN MODEL: 510-721 BN



KEY FEATURES



OVEN FUNCTIONS



510-711 X

Built-in 60 cm gas oven with grill and rotisserie

Key features

Stainless steel design
Rotisserie
Flame failure safety device
Electronic ignition
Cooling fan
Easy removable door
Minute minder

Oven accessories:

tray, shelf,
rotisserie kit

Overall dimensions:

H 595 x W 595 mm

Colours also available:

BLACK MODEL: 510-711 BK

WHITE MODEL: 510-711 WH

BROWN MODEL: 510-711 BN



KEY FEATURES



OVEN FUNCTIONS



512-7GTC	512-7GTC M	512-731 (c)	511-731 (c)	510-821 (c)	510-721 (c)	510-711 (c)	MODELS
							COLOUR (c)
		■	■	■	■	■	Stainless steel (X)
				■	■	■	White (WH)
■				■	■	■	Black (BK)
	■						Mirror (M)
				■	■	■	Brown (BN)
							FUNCTIONS
5	5	5	3	3	3	3	Cooking mode
■	■	■	■	■	■	■	Rotisserie
							Thermostatic electric grill
				■			Electric grill
■	■	■					Forced air convection
■	■	■	■	■	■	■	Gas oven
■	■	■	■		■	■	Gas grill
							PERFORMANCE
				2.00			Electric Grill element (kW)
2.70	2.70	2.70	2.70	2.70	2.70	2.70	Gas Oven burner (kW)
1.70	1.70	1.70	1.70		1.70	1.70	Gas Grill burner (kW)
							FEATURES
							Touch control programmer
■	■	■	■				Electronic digital clock
				■	■	■	Minute Minder
							SAFETY
130°/240°	130°/240°	130°/240°	130°/240°	130°/240°	130°/240°	130°/240°	Thermostat
■	■	■	■	■	■	■	Cooling fan
2	2	2	2	2	2	2	Door glass panels
■	■	■	■				Removable inner door glass
■	■	■	■	■	■	■	Automatic ignition
■	■	■	■	■	■	■	Flame failure safety device
							INTERNAL
black	black	black	black	black	black	black	Cavity enamel
1	1	1	1	1	1	1	Light
■	■	■	■				Catalytic self-cleaning panels
1	1	1	1	1	1	1	Tray
				1	1	1	Shelf
1	1	1	1				Shaped shelf
1	1	1	1	1	1		Pastry plate
							SPECIFICATIONS
54	54	54	59	63	59	59	Net volume (litres)
78	78	78	78	78	78	78	Gross volume (litres)
2700	2700	2700	2700	2700	2700	2700	Total gas input (W)
							230 volt 50Hz voltage
60	60	60	39	2039	39	39	max electric input (W)
■	■	■	■	■	■	■	CE Mark
595x595	595x595	595x595	595x595	595x595	595x595	595x595	Dimensions (HxW) mm
560x591x550	560x591x550	560x591x550	560x591x550	560x591x550	560x591x550	560x591x550	Cut-out dimensions (WxHxD) mm